WARNINGS

Don't drop, dissemble or attempt to repair the charger by yourself.
Avoid exposure to water or high humidity.
Don't expose to any heat source.
Keep out of reach of children.
Don't use in the presence of flammable gas.

WAARSCHUWING

Probeer de solar lader niet zelf te repareren of te demonteren.
Vermijd blootstelling aan water of een hoge luchtvochtigheid.
Niet blootstellen aan een warmtebron.
Buiten bereik van kinderen houden.
Niet gebruiken in de aanwezigheid van brandbaar gas.

ACHTUNG

Öffnen Sie nicht selbst den Lader. (Garantieverlust)
Vermeiden Sie den Betrieb bei hoher Luftfeuchtigkeit oder Einwirkung von Wasser.
Halten Sie den Lader fern von Hitzequellen.
Den Lader bitte fern von Kindern halten.
Das Gerät nicht verwenden in der Nähe von brennbaren Gasen oder Flüssigkeiten.

ATTENTION

Ne laissez pas tomber, de désassembler ou tenter de réparer la centrale par vous-même.
Eviter l'exposition á l'eau ou à uni humidité élevée.
Ne pas exposer la centrale électrique d'une source de chaleur.
Tenir hors de portée des enfants.
Ne pas utiliser en présence de gaz inflammables.

ATTENZIONE

Non usare vicino ad una fiamma.
Non esporre vicino a fonti di calore elevato
Non modificare la struttura o disassemblare
Smettere di utilizzare immediatamente nel caso si sentano odori strani, calore, o strani rumori provenire dallo stesso.
Non lasciar giocare bambini con.
Usare solo in luoghi asciutti.
Riciclare l'apparato secondo le norme vigenti nella nazione di utilizzo.

UPOZORNĚNÍ

Neupusťte, nerozebírejte, ani se nepokoušejte spravit nabíječku sami.
Vyvarujte se působení vody nebo vysoké vlhkosti.
Nevystavujte tepelným zdrojem.
Uchovávejte mimo dosah dětí.
Nepoužívejte v blízkosti hořlavých plynů.

UPOZORNENIA

Neupustite, nerozoberajte, ani sa nepokúšajte opraviť nabíjačku sami.
Vyvarujte sa pôsobeniu vody alebo vysokej vlhkosti.
Nevystavujte tepelným zdrojom.
Uchovávajte mimo dosahu detí.
Nepoužívajte v blízkosti horľavých plynov

VARNING

Tappa inte, ta inte isär eller försök reparera laddaren själv
Utsätt inte för vatten eller hög fuktighet
Utsätt inte för värme.
Förvaras utom räckhåll för barn.
Använd ej i närheten av lättantändlig gas.

A-solar
POWER EVERYWHERE

Hoofdveste 19
3992 DH Houten
The Netherlands
T: + 31 (0) 30 635 4800
F: + 31 (0) 30 635 4801
www.a-solar.eu

Portable Power Charger Solar/USB

AM-112 Platinum Plus **2.500mAh**

Thank you for purchasing our product

Dank u voor de aankoop van ons product

Vielen Dank, dass Sie sich für unser Produkt entschieden haben

Merci d'avoir acheté notre produit

Grazie per aver acquistato questo prodotto

Děkujeme vám za zakoupení tohoto výrobku

Ďakujeme vám za zakúpenie tohto výrobku

Tack för att du köpt vår produkt

Box contains

USB CABLE | PORTABLE POWER CHARGER | POUCH

SAMSUNG® | SONY ERICSSON® | LG® | SONY PSP®

MICRO USB | NINTENDO DSi® | MINI USB

Specifications:

Dimensions product (hxwxd)	**130x70x20mm**
Weight product	**100 grams**
Internal battery	**2500mAh**
Solar panel	**200mA**
Input	**5V/1A**
Output	**5V/ 1A**
Charging time Sunlight	**12-15 hours***
Charging time USB	**3-4 hours***
Charging time Mobile equipment	**2-4 hours***
LED battery indication	**Yes**
Internal USB output	**Yes**

1. Product overview



2. QUICK START / First use

PRE CHARGED

All A-solar chargers are pre-charged. This means that you can start charging your mobile devices without first having to charge your A-solar product!

Connect the usb cable into USB OUT

Connect into your mobile device using the connectors

Expect 2-4 hours* charging time

3. Charge the **Portable Power Charger** by **USB** or **A/C**

!!!

For first use we recommend that you charge the solar charger by USB with the included cable.



Connect the usb cable using the mini usb connector into USB IN

METHOD 1: Connect the usb cable into the USB PORT of your pc/laptop

METHOD 2: Connect the usb cable into your A/C adapter

Press the CHECK BUTTON and the LEDs indicate how far the charger is charging

Expect 3-4 hours* charging time

4. Charge the **Portable Power Charger** by **sunlight**


SUNLIGHT LED ORANGE
Best illumination angle
Best place to charge outside the house
Best time of the day
09:00-15:00
Do not left out in de rain
Best degree of cloudiness
09:00-15:00
4 leds = 100% charged
3 leds = 75% Charged
2 leds = 50% charged
1 led = 25% charged
No leds = empty
LED LIGHTS GREEN
CHECK BUTTON

Place the Charger in direct sunlight and the battery is charged automatically

Expect 12-15 hours* charging time

Please notice the following tips for optimum conditions

Press the CHECK BUTTON and the LEDs indicate how far the charger is charging

5. Charge your **mobile device**



Your mobile devicce is out of power

Connect into your mobile device using the connectors

Connect the usb cable into charger

Expect 2-4 hours* charging time

There will be a finished indicator in your mobile device when ready**

*** In optimum conditions ** this sign can be different for other devices**